

Manual, Assembly instruction: Brodit 804172

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant by the A-post slightly. Hook the angled edge on the lower part of the ProClip behind the A-post, under the rubber sealant.
2. Press upward/leftward on the ProClip so the angled upper edge hooks around the A-post by the windshield. Press until you hear/feel it snaps into place.
3. Slide the ProClip downward.
4. The ProClip is in place.