

Manual, Assembly instruction: Brodit 804182

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Hook the angled edge on the upper part of the ProClip around the A-post by the windscreen.
2. Press the thin end of the enclosed gap opener into the gap between the rubber seal and the A-post. Pull/flip the rubber sealant open. Pull out the gap opener.
3. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.
4. The ProClip is in place.