

Manual, Assembly instruction: Brodit 804211

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly.
2. Press the lower part of the ProClip into the gap under the rubber sealant and hook the angled edge around the A-post.
3. Press the ProClip upward/leftward so the angled edge on the upper part hooks around the A-post by the windshield. Press until you hear/feel it snaps into place.
4. The ProClip is in place.