

Manual, Assembly instruction: Brodit 804221

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Press the angled edge on the lower part of the ProClip into the gap between the A-post and the rubber sealant and hook it behind the A-post.
2. Press the ProClip forward so the angled edge on the upper part hooks around the A-post by the front side window.
3. Press the ProClip toward the A-post so it hooks into place properly and the adhesive tapes attach.
4. The ProClip is in place.