

Manual, Assembly instruction: Brodit 804243

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Hook the angled edge on the lower part of the ProClip into/around the air vent in the A-post panel.

2. Flip/push the upper part of the ProClip towards the windshield.

3. Press firmly upwards with your left hand on the bottom part of the ProClip and leftward on the right side of the ProClip with your other hand. When the angled edge on the upper part of the ProClip meets the windshield, press down on the right corner of the ProClip to get the angled edge goes into the gap between the windshield and the A-post panel. Then continue to press down over to the left corner of the ProClip.

4. The ProClip is in place.