

Manual, Assembly instruction: Brodit 804247

Left mount ONLY for Cabriolet.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the cover of adhesive tape on the ProClip. Press your thumb into the gap between the A-post panel frame and the rubber sealant, to widen the gap. Insert the ProClip in the gap.

2. Hook the angled edge on the lower part of the ProClip into the gap between the rubber sealant and the A-post panel.

3. Press firmly upwards with your left hand on the bottom part of the ProClip and leftward on the right side of the ProClip with your other hand. Press until you see or hear/feel the angled edge on the upper part of the ProClip hook around the A-post panel edge.

4. The ProClip is in place.