

Manual, Assembly instruction: Brodit 804253

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

- 1.** Pull the rubber sealant on the A-post slightly open. Peel off the adhesive tape covers on the ProClip. Insert the angled edge on the lower part of the ProClip into the gap under the rubber sealant and hook it behind the A-post panel edge.
- 2.** Press the ProClip forwards/upwards so the angled upper edge hooks around the A-post.
- 3.** Press until you see or hear/feel the angled edge on the upper part of the ProClip snap around the A-post panel edge by the front side window.
- 4.** The ProClip is in place.