

Manual, Assembly instruction: Brodit 804258

Left mount

1.)



2.)



3.)



4.)



NOTE: Care must be taken by installer when fitting the ProClip otherwise damage may be caused to the vehicles fabric. Brodit will not be held responsible for any damage caused to the vehicle during installation & de-installation. Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly to widen the gap.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post.
3. Press the ProClip upward/leftward so the angled edge on the upper part hooks around the A-post by the windshield.
4. The ProClip is in place.