

Manual, Assembly instruction: Brodit 804272

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin angled edge of the enclosed gap opener into the gap between the A-post and the front side window, to widen the gap. Peel off the adhesive tape cover on the ProClip.
2. Press the angled edge of the ProClip into the gap between the rubber sealant and the A-post and hook it around the A-post.
3. Press the ProClip forward/upward so the angled edge hooks into the gap above the gap opener. Pull out the gap opener.
4. The ProClip is in place.