

Manual, Assembly instruction: Brodit 804275

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull the rubber sealant on the A-post out slightly to widen the gap. Press the angled edge on the ProClip into the gap and hook it behind the A-post.
2. Press forward on the ProClip so the angled edge hooks around the A-post by the windscreen.
3. Press the ProClip toward the A-post so the angled edge hooks into place properly.
4. The ProClip is in place.