

Manual, Assembly instruction: Brodit 804288

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the A-post and the rubber sealant and pull out the rubber sealant slightly to widen the gap.
2. Press the angled edge of the ProClip into the gap and hook it around the A-post.
3. Press forward/upward on the ProClip so the angled edge hooks around the A-post by the windshield.
4. The ProClip is in place.