

Manual, Assembly instruction: Brodit 804290

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of the adhesive tape on the ProClip. Pull out the rubber sealant on the A-post slightly to widen the gap.

2. Press the angled edge of the ProClip into the gap and hook it around the A-post.

3. Press forward/upward on the ProClip so the angled edge hooks around the A-post by the small side window.

4. The ProClip is in place.