

Manual, Assembly instruction: Brodit 804292

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the thin end of the enclosed gap opener into the gap on top of the dashboard, to widen the gap.

2. Press the angled edge on the upper part of the ProClip into the gap next to the gap opener. Use the gap opener to widen the gap so the angled edge goes all the way into the gap. Pull out the gap opener.

3. Pull the ProClip toward you and hook the angled edge on the lower part under the upper edge of the air vent.

4. The ProClip is in place.