

Manual, Assembly instruction: Brodit 804300

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealent on the A-post slightly to widen the gap.
2. Press the angled edge on the ProClip into the gap and hook it behind the A-post.
3. Press the ProClip forward/upward so the angled edge hooks around the A-post by the front side window.
4. The ProClip is in place.