

Manual, Assembly instruction: Brodit 804351

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

2. Press the ProClip upward/forward so the angled edge on the upper part hooks around the A-post by the windshield. Press the upper part of the ProClip toward the A-post so the angled edge hooks properly in place.

3. The ProClip is in place.

4. The ProClip is in place.