

Manual, Assembly instruction: Brodit 804395

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

2. Press the upper part of the ProClip leftward so the angled edge hooks around the A-post.

3. The ProClip is in place.

4. The ProClip is in place.