

Manual, Assembly instruction: Brodit 804425

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly, to widen the gap.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip upward/forward and hook the angled upper edge over the A-post by the windshield. Press down on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.