

Manual, Assembly instruction: Brodit 804428

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

2. Place the enclosed gap opener onto the frame surrounding the air vent. Adjust the ProClip position so the lower edge is placed one gap opener height over the dashboard.

3. Press the thin end of the gap opener into the gap between the A-post and the windshield, to widen the gap. Press the ProClip upward/leftward so the upper angled edge hooks into the gap next to the gap opener. Press down on top of the ProClip so the angled edge hooks into place properly. Pull out the gap opener.

4. The ProClip is in place.