

Manual, Assembly instruction: Brodit 804431

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin end of the enclosed gap opener into the gap in the dashboard, to widen the gap. Peel off the cover of the adhesive tape on the ProClip.
2. Press the upper edge of the grooved part of the ProClip into the gap below the gap opener.
3. Press forwards on the lower part of the ProClip so the grooved part goes all the way into the gap. Press until you hear/feel it snaps into place. Pull out the gap opener.
4. The ProClip is in place.