

Manual, Assembly instruction: Brodit 804438

Left mount NOT for GTC model.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Place the left part of the ProClip so the grooves match the air vent sections.
2. Hook the angled left part of the ProClip into the lower part of the air vent.
3. Press forward on the ProClip so the angled right edge hooks around the post by the window. Press on the right part of the ProClip so the angled edge hooks properly in place.
4. The ProClip is in place.