

Manual, Assembly instruction: Brodit 804445

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealent on the A-post slightly, to widen the gap.

2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

3. Press the ProClip upward/leftward so the upper angled edge hooks around the A-post. Press down on top of the ProClip so the angled edge hooks into place properly.

4. The ProClip is in place.