

Manual, Assembly instruction: Brodit 804455

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealant on the A-post slightly, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post.
2. Press the ProClip upward/forward so the angled upper edge hooks around the A-post by the windshield.
3. Press the upper part of the ProClip toward the A-post so the angled edge hooks into place properly.
4. The ProClip is in place.