

Manual, Assembly instruction: Brodit 804464

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip forward so the angled upper edge hooks around the A-post.
3. Press the upper part toward the A-post so the angled edge goes all the way into the gap.
4. The ProClip is in place.