

Manual, Assembly instruction: Brodit 804481

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Press the thin angled edge of the enclosed gap opener into the gap between the A-post and the windscreen, to widen the gap. Peel off the adhesive tape covers on the ProClip.

2. Pull out the rubber sealant on the A-post slightly, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

3. Press the ProClip forward so the angled upper edge hooks into the gap below the gap opener. Pull out the gap opener.

4. The ProClip is in place.