

Manual, Assembly instruction: Brodit 804525

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the gap between the control panel and the dashboard, to widen the gap. Press the angled edge on the lower part of the ProClip into the gap next to the gap opener.

2. Flip the ProClip forward so the angled edge on the lower part hooks behind the control panel. Pull out the gap opener. Press the gap opener into the gap between the frame surrounding the air vent and the dashboard.

3. Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Press down on top of the ProClip so the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.