

Manual, Assembly instruction: Brodit 804572

Left mount



Please read all instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the left part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip forward so the angled edge on the right part hooks around the A-post.
4. The ProClip is in place.