

Manual, Assembly instruction: Brodit 804589

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post.
3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post. Press down on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.