

Manual, Assembly instruction: Brodit 804613

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the part of the ProClip with adhesive tape into the gap and hook it around the A-post.
3. Press the ProClip forward so the angled edge hooks around the A-post. Press until you hear/feel it snaps into place.
4. The ProClip is in place.