

Manual, Assembly instruction: Brodit 804624

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward/leftward so the upper angled edge hooks around the A-post.
3. Press downward on top of the ProClip until you hear/feel that the angled edge snaps into place.
4. The ProClip is in place.