

Manual, Assembly instruction: Brodit 804627

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward/leftward so the angled upper edge hooks around the A-post by the windshield.
3. Press down on top of the ProClip so the angled edge hooks properly into place.
4. The ProClip is in place.