

Manual, Assembly instruction: Brodit 804670

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealant on the A-post slightly.

2. Press the angled edge of the ProClip into the gap and hook it around the A-post.

3. Press the ProClip forward/leftward so the other angled edge hooks around the A-post. Press the ProClip toward the A-post so the angled edge hooks properly into place.

4. The ProClip is in place.