

Manual, Assembly instruction: Brodit 804687

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip forward/upward so the upper angled edge hooks around the A-post. Press the ProClip toward the A-post so the angled edge hooks properly into place.
4. The ProClip is in place.