

Manual, Assembly instruction: Brodit 804695

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly.

2. Press the angled edge on the lower part of the ProClip against the part of the rubber sealant that lies onto the A-post so the edge lifts the rubber sealant and is inserted under it. Hook the angled edge around the A-post.

3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post by the windshield. Press down on top of the ProClip until you hear/feel it clicks into place properly.

4. The ProClip is in place.