

Manual, Assembly instruction: Brodit 804714

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Pull/flip the rubber sealant on the A-post open. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.

2. Press firmly leftward on the right side of the ProClip until you see or hear/feel the angled edge on the upper part of the ProClip hook around the A-post panel edge by the windshield.

3. The ProClip is in place.

4. The ProClip is in place.