

Manual, Assembly instruction: Brodit 804716

Left mount, High



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Pull/flip the rubber sealant on the A-post open. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.

2. Press firmly upwards with your left hand on the bottom part of the ProClip and leftward on the right side of the ProClip with your other hand. Press until you see or hear/feel the angled edge on the upper part of the ProClip hook around the A-post panel edge by the windshield.

3. The ProClip is in place.

4. The ProClip is in place.