

Manual, Assembly instruction: Brodit 804736

Left mount, High NOT for models with A-post handle.

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward/forward so the angled upper edge hooks around the A-post.
3. Press down on top of the ProClip so the angled edge is properly in place.
4. The ProClip is in place.