

Manual, Assembly instruction: Brodit 804748

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward and forward so the upper angled edge hooks around the A-post by the windshield.
3. Press down on top of the ProClip so the upper angled edge hooks around the A-post properly.
4. The ProClip is in place.