

Manual, Assembly instruction: Brodit 804753

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull/flip the rubber sealant on the A-post open.
2. Insert the angled edge on the lower part of the ProClip into the gap and hook it behind the A-post panel edge.
3. Press the ProClip upward/forward so the upper angled edge hooks over the A-post by the windshield. Press down on top of the ProClip so the angled edge hooks into place properly.
4. The ProClip is in place.