

Manual, Assembly instruction: Brodit 804765

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Hook the angled edge on the upper part of the ProClip over the lower edge of the air vent.
2. Hook the angled edge on the upper part of the ProClip over the lower edge of the air vent.
3. Pull the ProClip toward you and hook the angled edge on the lower part under the upper edge of the air vent.
4. The ProClip is in place.