

Manual, Assembly instruction: Brodit 804769

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hook the front side of the ProClip around the A-post edge.

2. Press firmly upwards with your right hand on the right side of the ProClip. Press until you see or hear/feel the angled edge on the upper part of the ProClip hook around the A-post panel edge by the windshield.

3. The ProClip is in place.

4. The ProClip is in place.