

Manual, Assembly instruction: Brodit 804770

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Place the ProClip over the air vent part of the dashboard so the thin end on the lower part of the ProClip meets the seem between the two panel sections of the dashboard. Press down on the ProClip so the thin end goes all the way into the seem/gap.

2. Press the thin end of the enclosed gap opener into the seem/gap between the dashboard and the air vent, to widen the gap. Pull the upper part of the ProClip so it flexes upward and hook the angled edge into the gap next to the gap opener.

3. Press firmly down on top of the ProClip to make sure the angled edge goes all the way into the gap. Pull out the gap opener.

4. The ProClip is in place.