

Manual, Assembly instruction: Brodit 804794

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the cover of adhesive tape on the ProClip. Hold the ProClip in an almost 45 degree angle towards the dashboard and press the angled edge on the lower part of the ProClip into the seam/gap between padded part of the dashboard below the air vent and the dashboard trim.

2. Press the lower part of the ProClip further into the gap and at the same time flip the ProClip towards the upper part of the air vent.

3. Press firmly down on top of the ProClip so the angled edge goes into the seam.gap between the air vent and the padded part of the dashboard.

4. The ProClip is in place.