

## Manual, Assembly instruction: Brodit 804801

Left mount

1.)



2.)



3.)



4.)



**Please read all of the instructions and look at the pictures before attaching the ProClip.**

**1.** Press the thin end of the enclosed gap opener into the gap between the frame surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip.

**2.** Press the angled edge on the lower part of the ProClip into the gap under the dashboard surrounding the air vent. Press the lower part of the ProClip upward so all of the angled edge goes into the gap.

**3.** Hook the angled edge on the upper part of the ProClip into the gap next to the gap opener. Pull out the gap opener.

**4.** The ProClip is in place.