

Manual, Assembly instruction: Brodit 804803

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Hook the angled edge on the lower part of the ProClip under the upper edge of the air vent.
2. Press the ProClip forward so the angled edge on the upper part hooks into the gap between the frame surrounding the air vent and the dashboard.
3. Press downward on top of the ProClip so the angled edge goes all the way into the gap.
4. The ProClip is in place.