

Manual, Assembly instruction: Brodit 804818

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip. It is important to place this ProClip in the exact same position as shown in the pictures.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Pull out the rubber sealent on the A-post slightly. Note the small part of the A-post, the ProClip is to be installed directly below it. Place the upper edge of the lower part of the ProClip by the arrow shown in the picture.

2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

3. Press the ProClip upward/forward and hook the angled upper edge around the A-post. Press down on top of the ProClip so the angled edge goes all the way into the gap.

4. The ProClip is in place.