

Manual, Assembly instruction: Brodit 804826

Left mount



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Press the thin end of the enclosed gap opener into the seam/gap between the dashboard and the air vent panel frame, to widen the gap.

2. Flip the ProClip into an almost horizontal position (inside facing up) and press the angled edge on the lower part into the gap next to the gap opener. Pull out the gap opener.

3. Flip the ProClip upward towards the air vent. Press the gap opener into the seam/gap between the dashboard and the air vent panel frame. Press firmly forward on the upper part of the ProClip so the grooved upper edge goes into the gap next to the gap opener. Press until you see, hear or feel the ProClip click into place. Pull out the gap opener.

4. The ProClip is in place.