

Manual, Assembly instruction: Brodit 804835

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly.
2. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.
3. Press the ProClip upward/forward so the angled upper edge hooks around the A-post. Press down on top of the ProClip so you hear/feel it snaps into place.
4. The ProClip is in place.