

Manual, Assembly instruction: Brodit 804851

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the short part of the ProClip into the gap and hook it around the A-post.
2. Press the ProClip upward/forward and hook the angled edge on the long part around the A-post.
3. Press the long part of the ProClip toward the A-post so the angled edge goes all the way into the gap.
4. The ProClip is in place.