

Manual, Assembly instruction: Brodit 804858

Left mount

1.)



2.)



3.)



4.)



Please read all of the instructions and look at the pictures before attaching the ProClip.

1. Peel off the adhesive tape covers on the ProClip. Pull out the rubber sealant on the A-post slightly. Press the angled edge on the lower part of the ProClip into the gap and hook it around the A-post.

2. Press the ProClip upward/forward and hook the angled edge on the upper part around the A-post.

3. Press the upper part of the ProClip toward the A-post so the angled edge goes all the way into the gap.

4. The ProClip is in place.