

Manual, Assembly instruction: Brodit 804905

Left mount



Please read the instructions and look at the pictures before installing the ProClip.

1. Press the thin end of the enclosed gap opener into the lower gap between the panel surrounding the air vent and the dashboard, to widen the gap. Use the enclosed alcohol pad to clean the area where the ProClip is to be installed. Peel off the adhesive tape cover on the ProClip. Press the bent edge of the lower part of the ProClip into the gap next to the gap opener.

2. Pull out the gap opener. Press the gap opener into the upper gap between the panel surrounding the air vent and the dashboard. Press the upper part of the ProClip forward. Press the angled upper edge of the ProClip into the gap next to the gap opener.

3. Press the upper part of the ProClip downward so it goes all into the gap and the adhesive tape attaches properly. Pull out the gap opener.

4. The ProClip is in place.